



1. 6-INCH ZIP SYSTEM TAPE
 2. ZIP SYSTEM ROLLER. ROLL ALL TAPE.
 3. INSTALL DOOR JAMB PER DOOR MANUFACTURER.
 4. APPLY SEALANT* TO THE BACK SIDE OF THE DOOR MOLDING.
 5. INSTALL DOOR MOLDING
 6. INSTALL CODE APPROVED HEAD FLASHING.
 7. ZIP SYSTEM TAPE OR ADHESIVE BACKED FLASHING (MEETING AAMA 711 OR AC148).
 8. ZIP SYSTEM ROLLER. ROLL ALL TAPE.
 9. FROM THE INTERIOR, INSTALL LOW PRESSURE POLYURETHANE FOAM BETWEEN DOOR AND ROUGH OPENING TO MAINTAIN CONTINUITY OF THE AIR BARRIER. IF GAP IS TOO NARROW USE A COMPATIBLE CAULK SEALANT*.
- *WHEN APPLYING A SEALANT TO ZIP SYSTEM TAPE, USE A BUTYL, 100% SILICONE OR POLYURETHANE BASED SEALANT.

NTS