



1. APPLY A CONTINUOUS BEAD OF SEALANT AROUND THE FULL PERIMETER OF THE BACK SIDE OF THE DOOR MOUNTING FLANGE.
 2. INTERIOR SURFACE OF DOOR FLANGE
 3. SEALANT*
 4. INSTALL SEALANT* PER DOOR MANUFACTURER.
 5. ZIP SYSTEM™ TAPE OR ADHESIVE BACKED FLASHING (MUST MEET AAMA 711 OR AC148) OVER DOOR JAMB FLASHING AND HEAD FLANGES.
 6. INSTALLED DOOR.
 7. ENSURE JAMB FLASHING DOES NOT EXTEND MORE THAN HALF WAY THROUGH THE HEAD FLASHING.
 8. EXTEND THE HEAD FLASHING BEYOND THE JAMB FLASHING A MINIMUM OF 1-INCH.
 9. ZIP SYSTEM ROLLER. ROLL ALL TAPE.
 10. FROM THE INTERIOR, INSTALL LOW PRESSURE POLYURETHANE FOAM BETWEEN DOOR AND ROUGH OPENING TO MAINTAIN CONTINUITY OF THE AIR BARRIER. IF GAP IS TOO NARROW USE A COMPATIBLE CAULK SEALANT*.
- *WHEN APPLYING A SEALANT TO ZIP SYSTEM TAPE, USE A BUTYL, 100% SILICONE OR POLYURETHANE BASED SEALANT*.

NTS

05-02-2018
**ZIP SYSTEM® SHEATHING AT TYPICAL
 FLANGE DOOR**

D-2

Questions? Call us at 800.933.9220 ext. 2716
 or visit our website at zipsystem.com

ZIPsystem™
 SHEATHING & TAPE