



1. ZIP SYSTEM® SHEATHING*.
 2. INSTALLED FLANGED WINDOW. PLEASE SEE AVAILABLE WINDOW FLASHING DETAILS AT HUBERWOOD.COM.
 3. ZIP SYSTEM STRETCH TAPE OR ADHESIVE BACKED FLASHING MEETING AAMA 711 OR AC148.
 4. ZIP SYSTEM™ TAPE OR ADHESIVE BACKED FLASHING MEETING AAMA 711 OR AC148.
 5. EXTERIOR FOAM. INSTALL MECHANICALLY PER FOAM MANUFACTURER. DO NOT ADHESIVELY ATTACH.
 6. FROM THE INTERIOR, INSTALL LOW PRESSURE POLYURETHANE FOAM BETWEEN WINDOW AND ROUGH OPENING TO MAINTAIN CONTINUITY OF THE AIR BARRIER. IF GAP IS TOO NARROW USE A COMPATIBLE CAULK SEALANT*.
 7. CONTINUOUS BEAD OF SEALANT* AROUND THE BACK SIDE (INTERIOR SURFACE) OF THE WINDOW MOUNTING FLANGE.
 8. CODE APPROVED HEAD FLASHING (ONLY REQUIRED WHEN BUILT-IN DRAINAGE CHANNELS ARE NOT APART OF THE WINDOW'S DESIGN).
- * WHEN APPLYING A SEALANT TO ZIP SYSTEM TAPE, USE A BUTYL, 100% SILICONE OR POLYURETHANE BASED SEALANT.
- NOTE: ALL TRIM DETAILS SHOULD BE DETERMINED BY THE DESIGNER OF RECORD, TRIM MANUFACTURER OR THE WINDOW MANUFACTURER.

NTS