



1. ZIP SYSTEM® SHEATHING\*.
  2. INSTALLED PICTURE FRAME WINDOW. PLEASE SEE AVAILABLE WINDOW FLASHING DETAILS AT [HUBERWOOD.COM](http://HUBERWOOD.COM).
  3. ZIP SYSTEM STRETCH TAPE OR ADHESIVE BACKED FLASHING MEETING AAMA 711 OR AC148.
  4. ZIP SYSTEM™ TAPE OR ADHESIVE BACKED FLASHING MEETING AAMA 711 OR AC148.
  5. CONTINUOUS BEAD OF SEALANT\* WHERE THE PICTURE FRAME MEETS THE SURFACE OF THE ZIP SYSTEM SHEATHING.
  6. PICTURE FRAMING. DETAIL BY OTHERS.
  7. EXTERIOR FOAM. INSTALL MECHANICALLY PER FOAM MANUFACTURER. DO NOT ADHESIVELY ATTACH.
  8. FROM THE INTERIOR, INSTALL LOW PRESSURE POLYURETHANE FOAM BETWEEN WINDOW AND ROUGH OPENING TO MAINTAIN CONTINUITY OF THE AIR BARRIER. IF GAP IS TOO NARROW USE A COMPATIBLE CAULK SEALANT\*.
  9. CONTINUOUS BEAD OF SEALANT\* AROUND THE BACK SIDE (INTERIOR SURFACE) OF THE WINDOW MOUNTING FLANGE.
  10. CODE APPROVED HEAD FLASHING (ONLY REQUIRED WHEN BUILT-IN DRAINAGE CHANNELS ARE NOT PART OF THE WINDOW'S DESIGN).
- \* WHEN APPLYING A SEALANT TO ZIP SYSTEM TAPE, USE A BUTYL, 100% SILICONE OR POLYURETHANE BASED SEALANT.
- NOTE: ALL TRIM DETAILS SHOULD BE DETERMINED BY THE DESIGNER OF RECORD, TRIM MANUFACTURER OR THE WINDOW MANUFACTURER.

NTS