



NTS

1. "PICTURE FRAME" BUILT OUT PER ARCHITECTURAL DRAWINGS.
 2. APPLY A CONTINUOUS BEAD OF SEALANT* IN THE CORNER OF THE INTERSECTION OF THE PICTURE FRAME AND THE SURFACE OF THE ZIP SYSTEM® SHEATHING.
 3. ZIP SYSTEM TAPE™ OR ADHESIVE BACKED FLASHING (MEETING AAMA 711 OR AC148) REACHING ONTO THE FACE OF ZIP SYSTEM® SHEATHING A MINIMUM OF 2 INCHES.
 4. ZIP SYSTEM™ STRETCH TAPE.
 5. ZIP SYSTEM™ ROLLER. ROLL ALL TAPE.
 6. INSIDE SURFACE OF WINDOW FLANGE.
 7. APPLY A CONTINUOUS BEAD OF SEALANT* AROUND THE BACK SIDE (INTERIOR SURFACE) OF THE WINDOW MOUNTING FLANGE.
 8. ZIP SYSTEM TAPE™ OR ADHESIVE BACKED FLASHING (MEETING AAMA 711 OR AC148) REACHING ONTO THE FACE OF ZIP SYSTEM® SHEATHING A MINIMUM OF 2 INCHES.
 9. ZIP SYSTEM™ STRETCH TAPE REACHING ONTO THE FACE OF ZIP SYSTEM® SHEATHING A MINIMUM OF 2 INCHES. INSTALL PIECE ALONG THE HEAD FIRST AND THEN INSTALL THE CORNER PIECES.
 10. ZIP SYSTEM™ ROLLER. ROLL ALL TAPE.
 11. MECHANICALLY FASTENED EXTERIOR FOAM.
 12. FROM THE INTERIOR, INSTALL LOW PRESSURE POLYURETHANE FOAM BETWEEN WINDOW AND ROUGH OPENING TO MAINTAIN CONTINUITY OF THE AIR BARRIER. IF GAP IS TOO NARROW USE A COMPATIBLE CAULK SEALANT*.
- *WHEN APPLYING A SEALANT TO ZIP SYSTEM TAPE, USE A BUTYL, 100% SILICONE OR POLYURETHANE BASED SEALANT.