



NTS

1. "PICTURE FRAME" BUILT OUT PER ARCHITECTURAL DRAWINGS.
 2. APPLY A CONTINUOUS BEAD OF SEALANT* IN THE CORNER OF THE INTERSECTION OF THE PICTURE FRAME AND THE SURFACE OF THE ZIP SYSTEM® SHEATHING.
 3. ZIP SYSTEM TAPE™ OR ADHESIVE BACKED FLASHING (MEETING AAMA 711 OR AC148) REACHING ONTO THE FACE OF ZIP SYSTEM® SHEATHING A MINIMUM OF 2 INCHES.
 4. ZIP SYSTEM™ STRETCH TAPE.
 5. ZIP SYSTEM™ ROLLER. ROLL ALL TAPE.
 6. INSIDE SURFACE OF WINDOW FLANGE.
 7. APPLY A CONTINUOUS BEAD OF SEALANT* AROUND THE BACK SIDE (INTERIOR SURFACE) OF THE WINDOW MOUNTING FLANGE.
 8. ZIP SYSTEM TAPE™ OR ADHESIVE BACKED FLASHING (MEETING AAMA 711 OR AC148) REACHING ONTO THE FACE OF ZIP SYSTEM® SHEATHING A MINIMUM OF 2 INCHES.
 9. ZIP SYSTEM™ STRETCH TAPE REACHING ONTO THE FACE OF ZIP SYSTEM® SHEATHING A MINIMUM OF 2 INCHES. INSTALL PIECE ALONG THE HEAD FIRST AND THEN INSTALL THE CORNER PIECES.
 10. ZIP SYSTEM™ ROLLER. ROLL ALL TAPE.
 11. FROM THE INTERIOR, INSTALL LOW PRESSURE POLYURETHANE FOAM BETWEEN WINDOW AND ROUGH OPENING TO MAINTAIN CONTINUITY OF THE AIR BARRIER. IF GAP IS TOO NARROW USE A COMPATIBLE CAULK SEALANT*.
- *WHEN APPLYING A SEALANT TO ZIP SYSTEM TAPE, USE A BUTYL, 100% SILICONE OR POLYURETHANE BASED SEALANT.