



1. ZIP SYSTEM™ STRETCH TAPE EXTENDED ZIP SYSTEM™ STRETCH TAPE UP THE JAMBS A MINIMUM OF 6-INCHES.
2. ZIP SYSTEM™ TAPE THE TAPE SHOULD EXTEND ON THE FACE OF THE ZIP SYSTEM® SHEATHING A MINIMUM OF 2-INCHES.
3. ZIP SYSTEM™ ROLLER. ROLL ALL TAPE.
4. SHIMS AS REQUIRED BY THE WINDOW MANUFACTURER.
5. BRICK MOULD WINDOW.
6. BACK SIDE OF BRICK MOULD WINDOW FLANGE.
7. APPLY A CONTINUOUS BEAD OF SEALANT* AROUND THE BACK SIDE (INTERIOR SURFACE) OF THE WINDOW MOUNTING FLANGE.
8. METAL HEAD FLASHING SECURED USING CODE APPROVED FASTENERS.
9. ZIP SYSTEM™ TAPE OR ADHESIVE BACKED FLASHING (MEETING AAMA 711 OR AC148).
10. ZIP SYSTEM™ ROLLER. ROLL ALL TAPE.
11. EXTEND THE HEAD FLASHING BEYOND THE METAL FLASHING A MINIMUM OF 1-INCH.
12. FROM THE INTERIOR, INSTALL LOW PRESSURE POLYURETHANE FOAM BETWEEN WINDOW AND ROUGH OPENING TO MAINTAIN CONTINUITY OF THE AIR BARRIER. IF GAP IS TOO NARROW USE A COMPATIBLE CAULK SEALANT*.

*WHEN APPLYING A SEALANT TO ZIP SYSTEM TAPE, USE A BUTYL, 100% SILICONE OR POLYURETHANE BASED SEALANT.

NTS

05-18-2018
**ZIP SYSTEM® SHEATHING AT TYPICAL
 BRICK MOULD WINDOW**

W-3

Questions? Call us at 800.933.9220 ext. 2716
 or visit our website at zipsystem.com