


- * Tape all ZIP System sheathing panel seams and roll the tape.
- * Tape all vertical seams of ZIP System rainscreen.
- * (Optional) Install a bug guard along the bottom of ZIP System rainscreen.
- * Trim the 3-inch selvage along the bottom course of ZIP System rainscreen.
- * The weep screed or J-channel should be sized to accommodate both the stucco and the ZIP System rainscreen (if applicable).
- * Confirm the weep screed or J-channel are perforated to allow drainage.

- ZIP System R-sheathing
- ZIP System Rainscreen
- ZIP System Flashing Tape
- Lath
- Stucco Scratch and Brown Coat
- Stucco Finish Coat
- Weep Screed
- ZIP System Liquid Flash for Foundation Transition (Optional)
- Backer Rod or Fiber-Reinforced Filler Material
- Sill Gasket




-BOTTOM OF WALL FLASHING DETAIL WITH STUCCO- ZIP SYSTEM RAINSCREEN OVER WEEP SCREED WITH ZIP SYSTEM R-SHEATHING

February 21, 2024

These construction details are provided to assist in the installation of ZIP System® product(s) and may not apply to every situation. Manufacturer accepts no responsibility or liability for the use of these or other construction details.


Page 1 of 3

ZIPsystem™
RAINSCREEN



- * Tape all ZIP System sheathing panel seams and roll the tape.
- * Tape all vertical seams of ZIP System rainscreen.
- * (Optional) Install a bug guard along the bottom of ZIP System rainscreen.
- * Trim the 3-inch selvage along the bottom course of ZIP System rainscreen.
- * The weep screed or J-channel should be sized to accommodate both the stucco and the ZIP System rainscreen (if applicable).
- * Confirm the weep screed or J-channel are perforated to allow drainage.

- ZIP System R-sheathing
- ZIP System Rainscreen
- ZIP System Flashing Tape for Kickout Flashing
- Lath
- Stucco Scratch and Brown Coat
- Stucco Finish Coat
- Kickout Flashing
- Weep Screed
- ZIP System Liquid Flash for Foundation Transition (Optional)
- Backer Rod or Fiber-Reinforced Filler Material
- Sill Gasket



-BOTTOM OF WALL FLASHING DETAIL WITH STUCCO- ZIP SYSTEM RAINSCREEN UNDER WEEP SCREED WITH ZIP SYSTEM R-SHEATHING

February 21, 2024

Page 2 of 3

ZIPsystem™
RAINSCREEN

These construction details are provided to assist in the installation of ZIP System® product(s) and may not apply to every situation. Manufacturer accepts no responsibility or liability for the use of these or other construction details.



ZIP System R-sheathing

ZIP System Rainscreen

ZIP System Flashing Tape for Kickout Flashing

Lath

Stucco Scratch and Brown Coat

Stucco Finish Coat

Kickout Flashing

ZIP System Liquid Flash
for Foundation Transition (Optional)

J-Channel

~ 1/2 Inch

Backer Rod or Fiber-Reinforced Filler Material

Sill Gasket

Code-Required 4-Inch
Clearance Above Grade

- * Tape all ZIP System sheathing panel seams and roll the tape.
- * Tape all vertical seams of ZIP System rainscreen.
- * (Optional) Install a bug guard along the bottom of ZIP System rainscreen.
- * Trim the 3-inch selvage along the bottom course of ZIP System rainscreen.
- * The weep screed or J-channel should be sized to accommodate both the stucco and the ZIP System rainscreen (if applicable).
- * Confirm the weep screed or J-channel are perforated to allow drainage.

-BOTTOM OF WALL FLASHING DETAIL WITH STUCCO- ZIP SYSTEM RAINSCREEN UNDER J-CHANNEL WITH ZIP SYSTEM R-SHEATHING

February 21, 2024

Page 3 of 3

ZIPsystem™
RAINSCREEN

These construction details are provided to assist in the installation of ZIP System® product(s) and may not apply to every situation. Manufacturer accepts no responsibility or liability for the use of these or other construction details.